



XLE OCS Model: HE-XE103
12 Digital DC Inputs / 12 Digital Outputs
2 Analog Inputs (Medium Resolution)

XLE OCS Model: HE-XE104
24 Digital DC Inputs / 16 Digital Outputs
2 Analog Inputs (Medium Resolution)

Want More Information?
To download the XLE User Manual (MAN0805), refer to *Technical Support* in this document.


1 Specifications

HE-XE103 / 104 Specifications					
Digital DC Inputs	XLE103	XLE104	Digital DC Outputs	XLE103	XLE104
Inputs per Module	12 including 4 configurable HSC inputs	24 including 4 configurable HSC inputs	Outputs per Module	12 including 2 configurable PWM outputs	16 including 2 configurable PWM outputs
Commons per Module	1		Commons per Module	1	
Input Voltage Range	12 VDC / 24 VDC		Output Type	Sourcing / 10 K Pull-Down	
Absolute Max. Voltage	35 VDC Max.		Absolute Max. Voltage	28 VDC Max.	
Input Impedance	10 kΩ		Output Protection	Short Circuit	
Input Current	Positive Logic	Negative Logic	Max. Output Current per point	0.5 A	
Upper Threshold	0.8 mA	-1.6 mA	Max. Total Current	4 A Continuous	
Lower Threshold	0.3 mA	-2.1 mA	Max. Output Supply Voltage	30 VDC	
Max Upper Threshold	8 VDC		Minimum Output Supply Voltage	10 VDC	
Min Lower Threshold	3 VDC		Max. Voltage Drop at Rated Current	0.25 VDC	
OFF to ON Response	1 ms		Max. Inrush Current	650 mA per channel	
ON to OFF Response	1 ms		Min. Load	None	
HSC Max. Switching Rate	10 kHz		OFF to ON Response	1 ms	
Analog Inputs, Medium Resolution	XLE103	XLE104	ON to OFF Response	1 ms	
Number of Channels	2	2	Output Characteristics	Current Sourcing (Pos logic)	
Input Ranges	0 - 10 VDC 0 - 20 mA 4 - 20 mA		General Specifications		
Safe input voltage range	-0.5 V to +12V				
Input Impedance (Clamped @ -0.5 VDC to 12 VDC)	100 Ω Voltage Mode: 500 k Ω		Required Power (Steady State)	130 mA @ 24 VDC	
Nominal Resolution	10 Bits		Required Power (Inrush)	30 A for 1 ms @ 24 VDC	
%AI full scale	32,000 counts		Primary Power Range	10 - 30 VDC	
Max. Over-Current	35 mA		Relative Humidity	5 to 95% Non-condensing	
Conversion Speed	All channels converted once per ladder scan		Operating Temperature	0° to 50° Celsius	
Max. Error at 25°C	TBD		Terminal Type	Screw Type, 5 mm Removable	
Additional error for temperatures other than 25°C	TBD		CE	See Compliance Table at http://www.heapg.com/Support/compliance.htm	
Filtering	160 Hz hash (noise) filter 1-128 scan digital running average filter		UL		
			Weight	12.5 oz. (354.36 g)	

2 Panel Cut-Out and Dimensions


Refer to XLE User Manual (MAN0805) for panel box information and a handy checklist of requirements.

Note:
The tolerance to meet NEMA standards is ± 0.005" (0.1 mm).



3 Ports / Connectors / Cables

Note: The case of the XLE is black, but for clarity, it is shown in a lighter gray color.




To Remove Back Cover:
Unscrew 4 screws located on the back of the unit. Lift lid.

CAUTION: Do not overtighten screws when screwing the lid back on.

I/O Jumpers: (Not Shown)


I/O Jumpers (JP) are located internally. To access, remove back cover of unit.

The I/O Jumpers, External Jumpers and Connectors (J1- J4) are described in the *Wiring and Jumpers* section of this document.



Power Connector

Power Up:
Connect to Earth Ground. Apply 10 - 30 VDC. Screen lights up.



CAN Connector

Use the CAN Connector when using CsCAN network.

Memory Slot:

Uses **Removable Memory** for data logging, screen captures, program loading and recipes.

Horner Part No.: HE-MC1

Serial Communications:

MJ1: Use for Escape programming and Application-Defined Communications.

MJ2: Use for Application-Defined Communications

Pin	MJ1 Pins	MJ2 Pins
8	TXD	OUT
7	RXD	IN
6	0 V	Ground
5	NC	No Connect
4	CTS	OUT
3	RTS	IN
2	RX- / TX-	IN / OUT
1	RX+ / TX+	IN / OUT

4 Wiring and Jumpers

Wire according to the type of inputs / outputs used and select the appropriate jumper option.



Wiring Specifications

•For I/O wiring (discrete), use the following wire type or equivalent: Belden 9918, 18 AWG or larger.

•For shielded Analog I/O wiring, use the following wire type or equivalent: Belden 8441, 18 AWG or larger.


•For CAN wiring, use the following wire type or equivalent: Belden 3084, 18 AWG or larger.

Location of I/O jumpers (JP) and wiring connectors (J1 – J4).



a. I/O Jumpers Settings (JP1 – JP3)

Note: The Cscape Module Setup configuration must match the selected I/O (JP) jumper settings.




b. External Jumpers Settings

The External Jumpers are used for termination of the RS-485 ports. The XLE is shipped unterminated.

To terminate, select one of the jumpers shipped with the product and insert it based upon the option that is desired.

As seen when looking at the top of the XLE unit. Refer to Section 3 for the location of the External Jumpers.




c. Wiring Examples

Note: The wiring examples show **Positive Logic** input wiring.


J1 Orange	XE103 / XE104 Name
I1	IN1
I2	IN2
I3	IN3
I4	IN4
I5	IN5
I6	IN6
I7	IN7
I8	IN8
H1	HSC1 / IN9
H2	HSC2 / IN10
H3	HSC3 / IN11
H4	HSC4 / IN12
A1	Analog IN1
A2	Analog IN2
0V	Ground

XE103 / 104 J1 Orange Positive Logic Digital In




J2 Black	XE103	XE104
0V	Ground	
V+	V+ *	
NC	No Connect	OUT13
Q12	OUT12	
Q11	OUT11	
Q10	OUT10	
Q9	OUT9	
Q8	OUT8	
Q7	OUT7	
Q6	OUT6	
Q5	OUT5	
Q4	OUT4	
Q3	OUT3	
Q2	OUT2 / PWM2	
Q1	OUT1 / PWM1	
V+* Supply for Sourcing Outputs		

XE103 / 104 J2 Black Positive Logic Digital Out




XE104 J4 Orange Positive Logic Digital Out



J3 Orange	XE104
I13	IN13
I14	IN14
I15	IN15
I16	IN16
I17	IN17
I18	IN18
I19	IN19
I20	IN20
I21	IN21
I22	IN22
I23	IN23
I24	IN24
0V	Ground



XE104 J3 Orange Positive Logic Digital In



001XLE047

5 Safety

When found on the product, the following symbols specify:



WARNING: To avoid the risk of electric shock or burns, always connect the safety (or earth) ground before making any other connections.

WARNING: To reduce the risk of fire, electrical shock, or physical injury it is strongly recommended to fuse the voltage measurement inputs. Be sure to locate fuses as close to the source as possible.

WARNING: Replace fuse with the same type and rating to provide protection against risk of fire and shock hazards.

WARNING: In the event of repeated failure, do not replace the fuse again as a repeated failure indicates a defective condition that will not clear by replacing the fuse.

WARNING: Only qualified electrical personnel familiar with the construction and operation of this equipment and the hazards involved should install, adjust, operate, or service this equipment. Read and understand this manual and other applicable manuals in their entirety before proceeding. Failure to observe this precaution could result in severe bodily injury or loss of life.

•All applicable codes and standards need to be followed in the installation of this product.

•Adhere to the following safety precautions whenever any type of connection is made to the module:

- Connect the safety (earth) ground on the power connector first before making any other connections.
- When connecting to electric circuits or pulse-initiating equipment, open their related breakers.
- Do not make connections to live power lines.
- Make connections to the module first; then connect to the circuit to be monitored.
- Route power wires in a safe manner in accordance with good practice and local codes.
- Wear proper personal protective equipment including safety glasses and insulated gloves when making connections to power circuits.
- Ensure hands, shoes, and floor are dry before making any connection to a power line.
- Make sure the unit is turned OFF before making connection to terminals.
- Make sure all circuits are de-energized before making connections.
- Before each use, inspect all cables for breaks or cracks in the insulation. Replace immediately if defective.